

**MERCEDES-BENZ**
**A. ΜΠΡΟΣΤΑ ΤΑΚΑΚΙΑ – FRONT BRAKE PADS**

FIBA No	WVA	MINTEX	ΕΦΑΡΜΟΓΕΣ APPLICATIONS	PRICE EURO
<b>FBP4141</b>	29853		<b>MERCEDES-BENZ</b> Atego 1 98-04, Sprinter 616 01-06, T2/LN1 86-96, Vario 96-	
<b>FBP4143</b>	20784 29784	MDB1585	<b>MERCEDES-BENZ</b> G-Class (W460) 79-93, (W461) 90-, (W463)/ Cabrio (W463) 90-, Henschel 2-t 73-77, T1 (601/602) 77-96, T1/TN 82-95, T2/L 68-88, T2/LN1 86-94, <b>VOLKSWAGEN</b> LT 40-55 I 79-89, <b>PUCH</b> G-Modell (W460) 79-92, (W461/W463) 90-	
<b>FBP4145</b>	29115 29148 29183		<b>MERCEDES-BENZ</b> Atego 2 04-, Atego 3 10-, <b>MAN</b> TGL 05-	
<b>FBP4146</b>	29042 29087 29105 29202		<b>DAF</b> CF65, CF75, CF85 01-, LF55 01-, XF95 01-06, XF105 05- <b>ERF</b> EC 03-, <b>EOBUS</b> Intouro 05-,NF3 Low Floor 98-, O 98-, Turismo 00-, <b>IVECO</b> Eurocargo 98-, Euromover 98-, Euro rider 98-00, Eurostar 98-03, Eurotech 98-03, Eurotrakker 99-05, My Way 98-00, Stralis 03-, Strator 10-, Trakker 04-, <b>MAN</b> HOCL 96-,TGA 03-08, TGM 05-, TGS 06-, TGX 07-, <b>MERCEDES-BENZ</b> Actros 96-, Antos 12-, Atego 1 98-04,Axor 01-, Axor 2 04-, Econic 98-, <b>NEOPLAN</b> Centroliner 98-, Cityliner 92-, Euroliner 92-, Jetliner 92-, Low-Floor 92-, Megaliner 92-, Megashuttle 92-, Skyliner 92-, Spaceliner 92-, Starliner 96-, Tourliner 03-, Transliner 92-, <b>RENAULT</b> Ares 99- <b>SCANIA</b> 114 94-04, 94/124/144/164 96-04, G/P/R/T 04-, <b>SETRA</b> S 01-, <b>SOLARIS</b> Alpino 07-, Urbino 99-, Vacanza 02-	
<b>FBP4147</b>	29093 29145		<b>IVECO</b> Eurocargo 00-, Eurofire 00-, Midirider 00-, <b>MAN</b> HOCL 96-, M2000 95-06, TGM 05-, <b>MERCEDES-BENZ</b> Atego 1 98-04, Atego 2 04-, Atego 3 10-	

**MERCEDES-BENZ****B. ΠΙΣΩ ΤΑΚΑΚΙΑ – REAR BRAKE PADS**

<b>FIBA No</b>	<b>WVA</b>	<b>MINTEX</b>	<b>ΕΦΑΡΜΟΓΕΣ APPLICATIONS</b>	<b>PRICE EURO</b>
<b>FBP4142</b>	29115 29183		<u>ΠΙΣΩ ΔΙΣΚΟΦΡΕΝΑ -REAR PADS</u> MERCEDES-BENZ Atego 1 98-04	